



1. HOSE SHOULD BE MOUNTED WITH TENSION ROUND THE TOWER BOLT
2. HOSE + TOWER BOLT WITH TENSION → BULKHEAD
3. HOLES IN BULKHEAD WILL BE DONE ONCE THE TOWER BOLT IS IN THE HOSE TO ASSURE A TIGHT CONNECTION WITH THE BULKHEAD.